

**Exp:03**

**Name: Hemanth kumar**

**Roll no:231901010**

## **Recover Deleted Files using Forensics Tools**

### **Aim**

To recover accidentally or intentionally deleted files from a storage device or disk image using forensic tools such as **Autopsy**, **FTK Imager** and verify the integrity of recovered data.

### **Algorithm / Steps**

#### **1. Prepare the Evidence Source**

- Acquire a forensic image of the target disk/USB drive (using FTK Imager or dd).
- Alternatively, mount the storage device in read-only mode.

#### **2. Open Forensic Tool**

- Launch Autopsy / FTK Imager .

#### **3. Load Data Source**

- Select *Add Data Source* → Provide the acquired image file or physical drive.

#### **4. Scan for Deleted Files**

- Enable file system analysis and data recovery modules.
- Locate “Unallocated Space” or “Deleted Files” sections.

#### **5. Recover Files**

- Select identified deleted files.
- Export/recover them to a safe forensic folder.

#### **6. Verify Recovered Data**

- Compare file hashes (MD5/SHA1) before and after recovery to ensure integrity.


#### **7. Generate Report**


- Document the recovered files, metadata (file name, size, location), and verification details.


## **Step-by-Step Procedure**


### **A. With FTK Imager**


1. Run **FTK Imager (as Administrator)**.
2. **File → Create Disk Image**.
3. Select **Physical Drive** → choose the USB stick.
4. Format: choose **E01** (preferred forensic format).
5. Destination: save in a folder like C:\Case\01\_Images\.
6. Tick **Verify images after creation**.
7. FTK will output MD5 & SHA1 → copy/save these hash values.















## B. Open Evidence in Autopsy

1. Launch **Autopsy**.
2. **Create New Case:**
  - Case Name: USB Deleted File Recovery.
  - Base Directory: C:\Case\02\_Working\.
3. **Add Data Source → Disk Image / VM File.**



- Browse to your .E01 or .dd image file from step 2.
  - Select **Time Zone**.
4. **Configure Ingest Modules** → tick:
- File Type Identification
  - Deleted Files / Carved Files
  - (Optional) Keyword Search, Hash Lookup
5. Start ingest → wait for Autopsy to process.

**Add Data Source**

**Steps**

1. Select Host
2. Select Data Source Type
- 3. Select Data Source**
4. Configure Ingest
5. Add Data Source

**Select Data Source**

Path:

☐ Ignore orphan files in FAT file systems

Time zone:

Sector size:

Bitlocker Password (optional):


Hash Values (optional):

MD5:

SHA-1:


SHA-256:

NOTE: These values will not be validated when the data source is added.



## C. Locate & Recover Deleted Files

1. Left panel → **Views** → **Deleted Files**.
2. Browse recovered entries (e.g., confidential.docx, image1.jpg).
3. Right-click file → **Extract File(s)**.
4. Save to: C:\Case\03\_Recovered\_Files\.



---

#### D. Verify Integrity with Hashes

1. Open **Command Prompt** in C:\Case\03\_Recovered\_Files\.
2. Run:
3. certutil -hashfile confidential.docx MD5
4. certutil -hashfile confidential.docx SHA1

Save results into a text file in C:\Case\04\_Hashes\.


5. Repeat for all recovered files.

```
E:\CASE\03_recovered files>certutil -hashfile _est.png SHA1
SHA1 hash of _est.png:
bc853316e2ef76d5361d48a9bbf9b0eec2b82629
CertUtil: -hashfile command completed successfully.

E:\CASE\03_recovered files>certutil -hashfile _est.png MD5
MD5 hash of _est.png:
b5d60c2a399fbde54bb235410123494e
CertUtil: -hashfile command completed successfully.

E:\CASE\03_recovered files>certutil -hashfile _otes.txt MD5
MD5 hash of _otes.txt:
2a2c01936cd5959d11bc7d8c8727b9d7
CertUtil: -hashfile command completed successfully.

E:\CASE\03_recovered files>certutil -hashfile _otes.txt SHA1
SHA1 hash of _otes.txt:
a091448a6d996187bac217b4e6ab29fe925acf6d
CertUtil: -hashfile command completed successfully.
```



## CONCLUSION:

The deleted-files recovery was completed successfully from a verified forensic image (E01) using Autopsy/FTK Imager. Recovered files were exported to 03\_Recovered\_Files/ and MD5/SHA1 hashes recorded in 04\_Hashes/ to preserve integrity. No changes were made to the original media; some files may be partially unrecoverable if overwritten prior to imaging.